




# Replaces Toro Groundsmaster 3280-D

## Parts

62in Rotary Deck - Model 30367  
Caster Wheels



All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Toro Groundsmaster 3280-D Parts

62in Rotary Deck - Model 30367  
Caster Wheels



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
<b>Tires &amp; Wheels</b>					
31	<b>R93-9938</b>	86-0020, 93-9938	Wheel Assy - Castor - Pneu 8x3.50-4	2	
32	<b>R93-9939</b>	93-9939, 98-2877	Tire - 8x3.50-4 (4 Ply) Sm Pneu	2	
32	<b>R150615</b>	136-4424, 137-5924	Tire - Foam Filled 8-3.5 x 4 Sm 4 Ply	2	
33	<b>R100-5832</b>	100-5832	Tube - Castor Wheel 2.80/2.50-4	2	
33	<b>R68-8950</b>	68-8950	Tube - Castor Wheel 9x3.50-4 TR87	2	
<b>Other Parts Available</b>					
50	<b>R69-6860</b>	69-6860	Washer - 1/8 - Caster Wheel	4	
51	<b>R104-0762-01</b>	104-0762-01	Caster Fork	2	
52	<b>R69-6470</b>	69-6470	Bushing - Flanged	4	
53	<b>R69-1510</b>	69-1510	Spacer - 1/2 Caster Fork	10	
54	<b>R92-9727</b>	92-9727	Cap Assy - HOC	2	
55	<b>R92-8861</b>	92-5582, 92-8861	Cap - HOC	2	
56	<b>R92-9726</b>	92-9726	Spring - Compression	2	
57	<b>R92-5583</b>	92-5583	Washer- Cap	2	
58	<b>R92-5581</b>	92-5581	Ring - Retaining	2	
60	<b>R93-4242</b>	93-4242	Plate - Caster Wheel	2	
61	<b>R32128-16</b>	32128-16	Locknut - 5/16-24 Flanged Top	8	
62	<b>R95-2741</b>	137-5552, 95-2741	Rim - Wheel Half w/o Valve Hole	2	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.



# Replaces Toro Groundsmaster 3280-D Parts

62in Rotary Deck - Model 30367  
Caster Wheels



Item No	R&R Part No.	OEM Part No.	Description	Qty Req	Order Quantity
63	<b>R93-4239</b>	93-4239	Rim - Wheel Half w/Valve Hole	2	
65	<b>R93-5980</b>	93-4238, 93-5980	Hub Assy - w/o Bearings/Spacer	2	
66	<b>R93-4241</b>	93-4241	Spacer - Caster Wheel	2	
67	<b>R93-4237</b>	93-4237	Bearing	4	
67	<b>R108-9017</b>	108-9017, 120-3366	Bearing-Stainless	4	
68	<b>R3296-53</b>	3296-53	Locknut - 5/8-11 ESNA Yellow	2	
69	<b>R327-24</b>	327-24	Bolt - Hex HD 5/8-11 x 6	2	

All original equipment manufacturers names and part numbers are used for identification purposes only, and we are in no way implying that our products are original equipment parts. Prices subject to change without notice.